

TC-7220 Stereo Amplifier and Speaker Selector Switch

This state of the art switching box allows you to select between or control two amplifiers or speakers in 2 different rooms or locations. The combined screw or banana plug terminals on the switch box allow secure and easy access for cables.

The TC-7220 two-way amplifier and speaker switch allows you to connect and switch between two amplifiers and two pairs of speakers.

The TC-7220 has silver plated switch contacts to minimize audio loss. Designed to suit speaker cable and working at amplified level, i.e. to be positioned after the amplifier, the TC-7220 has screw terminal connections for easily connecting speaker cable.

Stylish design - integrates perfectly with new Flat screen televisions and amplifiers.

Product Features

- Listen to amplifier A or B through one pair of speakers
- Listen to Speakers pair A or B from one amplifier

Connections

You can connect the speaker selector switch between an amplifier's speaker output terminals and the speaker input terminals.

Caution: Be sure to follow proper polarity (– to – and + to +) when making connections.

1. Connect amplifier A left speaker output terminals to the TC-7220 AMPLIFIER A L (left) negative (–) and positive (+) terminals and tighten its screws.
2. Connect the amplifier's right speaker output terminals to the AMP R (right) negative (–) and positive (+) terminals and tighten its screws.
3. Connect the first speaker system's left and right negative (–) and positive (+) terminals to the corresponding SPK A R and L terminals on the speaker selector switch and tighten its screws.
4. Connect the second speaker system's left and right negative (–) and positive (+) terminals to the corresponding SPK B R and L terminals on the speaker selector switch and tighten its screws.

OPERATION

1. Make sure that each audio amplifier is switched OFF, or that the speakers' output selector on the amplifiers is in the OFF position.
2. Press and select Amplifier A or B on the TC-7220 front panel, depending on which amplifier you wish to listen to.
3. Press and select Speaker A or B on the TC-7220 front panel, depending on which speaker pair you wish to listen to.
4. Now switch ON the amplifier(s).